
The NIF Ignition Campaign

**Presentation to
Heavy Ion Fusion Science – Virtual National Laboratory
Program Advisory Committee**




**Brian MacGowan
Physics & Systems Engineering
National Ignition Campaign**

Aug. 9, 2006

Work performed under the auspices of the U.S. Department of Energy by
the University of California, Lawrence Livermore National Laboratory under
Contract No. W-7405-ENG-48.

The National Ignition Campaign







Ignition experiments on NIF are the culmination of over 30 years of ICF research & development

Exploration of new physics regimes will begin with ignition experiments on NIF

National Ignition Campaign




- Execute credible ignition experiments in FY10 & FY11
- Prepare NIF for routine ignition experiments by end of FY12
- Complete NIF and NIC Primary Criteria and Functional Requirements




**Ignition
Target**


Ignition Point Design



Ignition Point Design



Ignition Point Design



The point design fully specifies the laser-target system

- Pulse shape, energy
- Spot size, uniformity
- DT ice layer roughness
- Capsule dimensions and surface roughness
- Hohlraum dimensions, materials, and efficiency
- Target thermal and position stability
- Diagnostics

Extract from the point design requirements document



The National Ignition Campaign


Number	Rev	Component	Title	short req't	Requirement Text
1	0	Target	Requirements apply at shot temperature	Requirements apply at shot temperature	All requirements on targets shall apply at the temperature of the subject component at the time of the shot
2	0	Target	Tolerances are specified as hard limits	Tolerances are hard limits	Unless specifically stated otherwise, all requirements on targets shall be hard limits (as opposed to statistical values such as 1 sigma, 3 sigma, or RMS). If targets are produced that do not meet hard-limit requirements, they shall be dispositioned on a case-by-case basis by an MRB.
3	0	Capsule	Capsule outer radius, range of possible requested values and point-design value	900-1100 μm	Capsules shall be producible with outer radii within the range 900 - 1100 μm . The outer radius of each capsule will be specified within this range. The point design value shall be 1.0 mm.
4	1	Capsule	Capsule outer radius, tolerance	$\pm 5\mu\text{m}$	The outer radius of the capsule shall be within +/- 5 μm of the specified value. On each shot the outer radius shall be measured to within +/- 1 μm .
5	0	Capsule	Ablator – Low level impurities	$\text{sum}(\text{atomic fraction}) * Z^2 < 0.1$	Except for allowed ingredients as listed in the ablator composition entries, the ablator material in all layers shall contain sufficiently low impurity levels that the sum over all impurities of atom fraction * Z^2 shall be less than or equal to 0.20, i.e. 20%. For example, a barely allowed impurity set would be [C,Al,Si,Mn,Fe,Ni] with atomic fractions 0.01*[.015,.007,.006,.0005,.021,.0031] giving Fe-dominated weighted sum $0.01*(.54+1.18+1.18+0.31+14.20+2.43)=0.20$
6	0	Capsule	Ablator – High level impurities with known acceptable presence		Ablators may contain specified materials as described in individual ablator composition requirements.
7	0	Capsule	Ablator – measurement of x-ray optical depth variations	accuracy <0.01%	Lateral variations in optical depth through the ablator shall be measured with accuracy better than 0.01%, at lateral scales between 120 and 3000 μm (modes 2–25), at 5.4 keV x-ray energy. Entire capsule shall be measured down to 120 μm lateral scale (mode 25). These measurements will constrain porosity, density variations, isolated defects, and variations in thickness of the internal layers. It will be very valuable to have scans of representative patches of representative capsules at lateral scans down to 20 μm (mode 150).

- The current version (rev 1) has 81 lines with supporting tables and drawings
- There are additional requirements for the campaigns leading up to ignition


Four Integrated Experiment Teams are developing the requirements for the campaigns leading up to ignition



The National Ignition Campaign




NIC Experimental Plan




NIF/NIC integrated summary schedule



The National Ignition Campaign



Major elements of the National Ignition Campaign



Process, assemble, and install 6,206 line replaceable units (LRUs)

**Preamplifier Modules
(48)**



**Laser Amplifiers
(672)**



**Final Optics Assemblies
(960)**



**Laser Mirrors
(656)**



**Spatial Filter Lenses
(960)**



**Spatial Filter Towers
(72)**



**Plasma Electrode
Pockels Cell (192)**



**Flashlamps
(1008)**




>2,300 LRUs installed to date


LRU Installation status – June 2006




The National Ignition Facility



LRU installations are now >36% complete







**Completed 2 bundles
of 8 beams each that
combined produced
300 kJ at 1ω**




NIF lasers meet all performance specifications


PQ shot energy, power, pulse shape and beam smoothing were achieved simultaneously

Single Bundle Performance Qualification Achieved (will be formally claimed when published)





User optics condition and size the beams as required by the point design




- All users optics have been demonstrated
- All meet ignition point design requirements

Multiple diagnostic and cryogenics systems will be commissioned for the FY10 ignition campaign



The National Ignition Campaign




The scope includes systems already in place, and new installations


**Diagnostic
Insertion
Manipulator
(DIM)**




Energetics diagnostics installed and working include Dante and FFLEX detector arrays



Dante diode array – time resolved radiation drive




FFLEX fluorescer array – hard x-ray spectrum

The image shows the interior of a target chamber, a complex scientific instrument. The chamber is a large, cylindrical structure with a highly reflective, metallic interior. The walls are composed of numerous small, rectangular panels arranged in a grid pattern. A laser beam, appearing as a bright red line, enters from the left and is focused on a central target area. The chamber is filled with various components, including numerous small, circular ports and larger, rectangular openings. The overall appearance is that of a highly sophisticated and precise piece of equipment.

**Target
Chamber
Interior**


Cryogenic Target System



Polished Be Capsule




Fill Tube




**Target
Fabrication**

DT Layer in Be Capsule




Cryogenic Hohlraum




DT ice layers in a carbon shell at 1.5 K below the melt meet the NIF roughness spec

X-ray phase contrast image



- NIF roughness spec for modes 7 and above is an RMS of 0.93 μm
- DT ice layers have been grown with an RMS of ≤ 0.9 μm for modes 7 and above



Personnel and Environmental Protection Systems (PEPS)

Provide systems to protect personnel and environment from radiation and materials produced by ignition yield

The NIC has brought together NNSA's ICF programs



The National Ignition Campaign

- **NIC is an enhanced managed program and is operated within a project framework and with project-like rigor**
- **Formation of the NIC “enterprise” has many benefits**
 - **Integrated budget and earned value management system**
 - **Integrated schedule and milestones**
 - **Integrated risk management across all activities at all sites**
 - **Integrated work breakdown structure**
 - **Improved and increased communications**
 - **Daily interactions, weekly VTCs, monthly and quarterly reviews**

We have a unified and focused goal of ignition on NIF

This is a national effort with important contributions from all participants



The National Ignition Campaign

Inst.	Scope
GA	Ignition capsule development, facilitization and production, hohlraum development and assembly
LANL	Ignition target design, LPI, Be ablator physics, neutron imaging, machined Be
LLE	Target exps. at OMEGA , target diagnostics cryogenic system design support, 4 th shock timing campaign lead
LLNL	National Ignition Campaign Director, NIF operation and capability and infrastructure, target cryogenic system, target diagnostics, user optics, PEPS, ICF design and experimental program
SNL	Cryogenic Target System x-ray shield design and manufacturing plan, collaborate on strategy for radiation neutron and EMP shielding of NIF diagnostics, Be shocked melt experiments on Z

- 
- Over the past year we have stood up the National Ignition Campaign
 - We now have a unified and focused effort for ignition on NIF including a credible ignition experiment in 2010

