

Physics Review of the Merging Beamlet Experiment

Components, Experimental Plan, and Project Status

Glen Westenskow

May 10, 2004

Outline


1. Hardware preparation

a. components

b. schedule and cost


2. Experimental approach

Elements of the Merging Experiment



Top plate

Captures existing plasma can




Insulator
(will be able to
measure current
into the source)

Prepared for the full-gradient experiment


Plasma chamber

STS-100 experiments




14 cm

Will not use the insulator shown in drawing




RF Power source (11 MHz)



Prepared for the full-gradient experiment

Example of a plate in the Einzel Lens Assembly



- 8 inch OD
- 1/8 inch thick
- SS material
- ~70 cm curvature
- 119 beamlets
- Alignment holes
- Rotated tabs (used to make electrical connection)

Extraction plate with Pierce Cone





Plate parameters


#	Voltage (kV)	Location (cm)	Ins	Gap Gradient (kV/cm)	Curvature (cm)
Extraction	400	0	S	18	66.13
1	384	1.25	S	36	64.89
2	352	2.45	S	-18	63.69
3	368	3.65	L	27	62.49
4	336	5.15	L	27	60.99
5	304	6.65	L	-27	59.49
6	336	8.15	L	27	57.99
7	304	9.65	L	27	56.49
8	272	11.15	L	-27	54.99
9	304	12.65	L	27	53.49
10	272	14.15	L	27	51.99
11	240	15.65	L	-	50.49

Plate thickness 0.32 cm


High-gradient insulators



9 units
2 cm OD
1.17 cm tall




27 units
2 cm OD
1.31 cm tall




HGIs used in STS100
Lens assembly


Connectors (between plates and column)




Connection to the top spool




Electric fields in merge region



Electrostatic Quadruples



Fabrication schedule



Hardware cost

Plates \$ 36 K

ESQ \$ 15 K

Feedthurs (ESQ power) \$ 5 K

Moveable Optical Diag. \$ 8 K


Misc (scope repair, shield, diagnostics) \$ 8 K

Total \$ 72K


(assuming we can get two +20kV PS from LBNL for ESQs)

Experimental approach

First stage: Measure current at the merge point with a F. Cup




Second stage: Capture image on a Kapton sheet




Kapton
Sheet


Third stage : Image beamlets



Four Stage: Install ESQs




Fifth stage: Measure phase space after ESQs



After we have characterized the beam in the standard configuration we will alter the hardware to study effect on the beam. Several examples follow:

Block beamlets



**Block holes at the
extraction plate
to study the effect on
beam quality**

Energy spectrometer

Could measure energy spread

At a reduced voltage we could use the Energy Spectrometer from STS-100